



USER GUIDE DRY MORTAR SILO



BATCHING

1. Turn on power to silo and press fault reset - red button.
2. Start motor - green button, make sure motor is spinning.
3. Slowly open the butterfly valve little at a time.
4. Adjust mortars consistency by adjusting the water flow (Red tap on the water pump).

The mixer timer is set to batch 1 full tub (0.33m³).

For lesser amounts press stop - red button.

It will then reset back to a full tub.



If leaving the silo for more than 1 hour between mixes - Start the silo, close the butterfly valve and keep the silo running until the water starts to pass through the mixer and runs clear, then press stop.

IMPORTANT

The silo mixer MUST be cleaned at the end of every day or in between long periods of not batching to avoid breakdown's and call out charges.

CLEANING

1. Start the Silo as per the above instructions.
2. Run until clear water passes through the mixer.
3. Press stop (red button) & Turn off the power to the mixer.
4. Using a 17mm spanner remove the top bolt off the mixer end cap then undo the clamps either side of the mixer cap.
5. Once the end cap is removed, slide out the mixer screw. Clean off any excess mortar from the screw and remove any excess material from within the mixer unit. (Do not put water inside the mixer)
6. Make sure the Screw is clean and dry then fit the screw back inside the mixer then fit the end cap and secure with clamps and top bolt.



FROST PROTECTION

1. It is essential pumps are removed in cold conditions and stored away from frost.
2. To remove the pump undo all water pipes.
3. Release the pump off the frame by undoing the bolts.



PUMPS DAMAGED BY FROST WILL BE CHARGEABLE ALONG WITH CALL OUT CHARGES.

Call: 01978 846976

Email: sales.mortar@holcim.co.uk

www.holcim.co.uk/products/mortar